



# CASEMENT WINDOW

## *Anatomy of a Casement Window*



Screen Clips



Hinge Bracket



Crank Handle

① **Head**

② **Frame**

③ **Sash**

④ **Sill**

⑤ **Jamb**

⑥ **Lock**

⑦ **Keepers**

# DOWNS

## How to clean and operate Casement Windows -

Casement Windows are easily cleaned from the interior of the home, and crank out effortlessly.

### TO CLEAN CASEMENT WINDOWS

- Turn screen clips to upright position to take screen out of track.
- Unlock the window by lifting the lock handle up. *(photo A)*.
- Crank the sash all the way to the open position *(photos B & C)*.
- Clean the exterior of the sash by reaching your arm through the space between the main frame and the sash *(photo D)*.
- When finished cleaning, close and lock the window by pushing the lock handle down.

### BOW AND BAY WINDOWS

Any exposed wood - head, jambs and seat boards - must be treated, sealed, stained or painted to prevent absorption of moisture and staining.


Republic recommends the following stains to stain Bow and Bay seats and trim to match Republic woodgrain colors.

LIGHT OAK FINISH: Minwax Wood Finish™ Natural 209

DARK OAK FINISH: Minwax Gel Stain™ Aged Oak 602

CHERRY FINISH: Minwax Wood Finish™ CHERRY 235

A



B



C



D

